


NOTES:

1. ALL PIPING BETWEEN HDPE AND CROSS BLOCK MUST BE RESTRAINED.
2. BELL TO BELL MJ REDUCER MAY BE USED TO GO FROM HDPE TO DIP. USE MEGALUG WITH PTFE POLYMER COATED BOLTS (EX. XYLAN, FLUOROKOTE #1) TO RESTRAIN ALL MJ FITTINGS.

PLAN



NOTES:

1. CENTER BLOCK ON PIPE.
2. SEE DWG. NO. 0201-0601-SD2 FOR OTHER TRANSITION OPTIONS.

UNDISTURBED SOIL
COMPACTED SOIL

SECTION A-A

REVISIONS

MISSOURI AMERICAN WATER STANDARD
CIVIL
HDPE TRANSITION
WITH REDUCER DETAIL

MISSOURI AMERICAN WATER
ST. LOUIS, MO. 63141

MISSOURI AMERICAN WATER ENGINEERING
727 CRAIG ROAD
ST. LOUIS, MO. 63141

DRAWN BY KKM
PROJECT ENG'R
APPROVED

DATE 09-16-11
PROJECT IP

USE DIMENSIONS ONLY
SCALE N.T.S.

USE APPROVED DRAWINGS ONLY
FOR CONSTRUCTION PURPOSES

0201-0601-SD21